
R1 Moto Series



User Manual

R1-8K

R1-10K

R1-10K5

RENAC

Content

1. Introduction.....	3
1.1 Introduction	3
1.2 Applied designations.....	3
1.3 Important safety information.....	4
1.4 System sizing	4
2. Technical description of inverters	5
2.1 Mechanical design	5
2.2 Electrical system design	6
2.3 Technical data	6
2.4 Grid codes.....	8
3. Installation and startup.....	9
3.1 Package information.....	10
3.2 Installation environment	10
3.3 Installation position	10
3.4 Mounting procedure	11
3.5 Electrical connection.....	13
3.5.1 Earth connection	13
3.5.2 Connection to the grid (AC output)	13
3.5.3 Connection to PV string (DC input)	15
3.5.4 Communication.....	16
3.5.4.1 WIFI / 4G / Ethernet communication (Optional).....	16
3.5.4.2 CT or Meter Connection (Optional).....	17
3.5.4.3 DRM connection	18
3.5.4.4 Relay connection	18
3.6 Starting the inverter	18
4. User interface	19
4.1 LED and key.....	19
4.2 LCD display.....	20
4.2.1 Language setting	21
4.2.2 Export power (CT) setting.....	22
4.2.3 Data and time setting.....	22
4.2.4 PV configuration setting	22
4.2.5 Communication address setting.....	22
4.2.6 Checking error logs	23
4.2.7 System switch setting.....	23
4.2.8 Inverter information checking.....	23
4.2.9 Country safety setting	23
4.2.10 DRMO setting	23
4.2.11 AFCI setting	24
4.2.12 Software upgrade	24
4.2.13 New password setting	24
4.2.14 Reset Setting	25

4.3 Self-Test in accordance with CEI 0-21 (Applies to Italy only)	25
5. Warranty	26
5.1 Warranty claim procedure.....	26
5.2 Service after warranty expiration	26
6. Troubleshooting and Maintenance	27
6.1 Troubleshooting.....	27
6.2 Maintenance	28
6.2.1 Routine Maintenance.....	29

1. Introduction

1.1 Introduction










This manual describes solar inverters: R1-8K / R1-10K / R1-10K5.

These inverters are transformerless based inverter.

Please read the safety instructions in this manual first. Throughout the manual it is assumed that the reader is familiar with AC and DC installations and knows the rules and regulations for electrical equipment and for connecting it to the utility grid. It is especially important to be familiar with the general safety rules for working with electrical equipment.


1.2 Applied designations

Throughout the manual important information is shown at different levels depending on the character of the information, as shown here:


	Safety information important for human safety. Violation of warnings may result in injury to persons or death.
	Danger of high voltage and electric shock!
	Signals danger due to electrical shock and indicates the time (5 minutes) to allow after the inverter has been turned off and disconnected to ensure safety in any installation operation.
	Danger of hot surface!
	Product should not be disposed as normal household waste.
	CE Mark
	ROHS Mark
	Information important for the protection of property. Violation of this type of information may cause damage and loss of property.
	Useful additional information or "Tips and Tricks" on specific subjects.

1.3 Important safety information

Read this before installing, operating or maintaining the inverter.

	<p>Before installation:</p> <p>Check for damage to inverter and packaging. If you are in doubt, please contact your supplier before installing the inverter. Check the voltages of the solar modules and make sure they are within the limits of the inverter specifications before connecting them to the inverter.</p>
	<p>Installation:</p> <p>Only trained and authorized personnel familiar with local electrical codes may install the inverter. For optimum safety, please follow the steps described in this manual. Keep in mind that the inverter has two voltage carrying sides, the PV input and the AC grid.</p>
	<p>Disconnecting the inverter:</p> <p>Always disconnect the AC line first! Afterwards disconnect the PV lines. Note that the inverter can still be charged with very high voltages at hazardous levels even when it is disconnected from grid and solar modules. Wait at least 5 min, before proceeding, after having disconnected from grid and PV panels. Don't open the MC4 connectors under load condition or inverter working condition.</p>
	<p>Operating the inverter:</p> <p>Before connecting the AC grid to the inverter, make sure that the installation cover is mounted again. The inverter must not be open during operation.</p>
	<p>Maintenance and modification:</p> <p>Only authorized personnel are allowed to repair or modify the inverter. To ensure optimum safety for user and environment, only the original spare parts available from your supplier should be used.</p>
	<p>Functional safety parameters:</p> <p>Unauthorized changes of functional safety parameters may cause injury or accidents to people or inverter. Additionally it will lead to the cancelling of all inverter operating approval certificates.</p>

1.4 System sizing

	<p>When dimensioning a photovoltaic system, it must be ensured that the open circuit voltage of the PV string never exceeds the maximum permissible input voltage of 600VDC. The PV string open circuit voltage during parallel string operation is 550V. Higher voltages may result in permanent damage to the inverter.</p>
---	---

The selection of PV string output should be based on the optimum utilization of the invested capital compared to the expected annual energy yield from the system. This optimization depends on local weather conditions and should be considered in each individual case.

The inverter incorporates an input power limiting device which automatically keeps the power at levels that are safe for the inverter. The limitation depends mainly on internal and ambient temperatures. The limitation is calculated continuously and always allows the maximum possible amount of energy to be produced.

Please use the tool supplied by Renac Power when dimensioning a photovoltaic system.

2. Technical description of inverters

2.1 Mechanical design

Figure 2-1 shows the outline dimensions of R1-8K / R1-10K / R1-10K5.




Figure 2-1 Outline dimensions

Figure 2-2 shows the electrical terminals of R1-8K / R1-10K / R1-10K5.




Figure 2-2 Electrical Terminals

1	DC Switch	5	AC terminal
2	DC terminal	6	LED (Run / Fault / Communication)
3	Communication port	7	LCD
4	I / O port	8	Key

2.2 Electrical system design



For safety reasons, the use of a DC switch is recommended. Between the PV modules and the power modules may be mandatory in some countries.




Figure 2-3 Block diagram of the inverter system

2.3 Technical data

Model	R1-8K	R1-10K	R1-10K5
PV Input Data			
Max. Recommended PV Power [Wp]	12000	15000	16000
Max. PV Power for Single MPPT [Wp]	6000	7500	7500
Max. PV Input Voltage [V]	600		
MPPT Voltage Range [V]	80 ~ 550		
Rated PV Input Voltage [V]	360		
Start-up Voltage [V]	100		
No. of MPP Trackers	2		
No. of Input Strings per Tracker	2 / 2	2 / 2	2 / 2
Max. PV Input Current [A]	32 / 32	32 / 32	32 / 32
Max. Short-circuit Current [A]	40 / 40	40 / 40	40 / 40
Max. Backfeed Current to Array [A]	0		
AC Output Data			
Rated AC Output Power [W]	8000	10000	10500
Max. AC Output Apparent Power [VA]	8800	10000	10500
Rated AC Voltage / Range [V]	L / N / PE, 220 / 230; 160 ~ 290		
Grid Frequency [Hz]	50 / 60; ±5		
Adjustable Power Factor [cosφ]	0.8 leading ~ 0.8 lagging		
Output THDi [@Rated Output]	< 3%		
Max. AC Output Current [A]	40	45.5	45.5



Model	R1-8K	R1-10K	R1-10K5
Max. Output Fault Current (Peak and Duration) (A)	110.29		
Inrush Current (Peak and Duration) (A)	0		
Maximum Output Overcurrent Protection (A)	80	91	91
Efficiency			
Max. Efficiency	98.1%	98.1%	98.1%
Euro Efficiency	97.5%	97.5%	97.5%
Protection			
DC Insulation Monitoring	Integrated		
Input Reverse Polarity Protection	Integrated		
Anti-island Protection	Integrated		
Residual Current Monitoring	Integrated		
Over-heat Protection	Integrated		
AC Overcurrent Protection	Integrated		
AC Short-circuit Protection	Integrated		
AC Overvoltage Protection	Integrated		
DC Surge Protection	Integrated (Type II)		
AC Surge Protection	Integrated (Type II)		
Arc fault circuit interrupter (AFCI)	Optional		
DC Switch	Optional		
General Data			
Dimension (W * H * D) [mm]	428 * 385 * 185		
Weight [kg]	17		
Display	LED + OLED		
Communication	RS485 and USB, WIFI, 4G(Optional), Ethernet(Optional)		
Ambient Temperature Range [°C]	-25 ~ +60		
Relative Humidity	0 ~ 100%		
Operating Altitude [m]	≤ 2000		
Night Self-consumption [W]	< 1		
Topology	Transformerless		
Cooling	Natural		
Ingress Protection	IP65		
Pollution Degree	III		
Overvoltage Category	DC II / AC III		
Protective class	I		
Noise [dB]	< 35		
Certifications & Standards			
Grid Regulation	ORDINANCE No.140		
Safety Regulation	IEC 62109-1, IEC 62109-2, EN 62919-1, EN62619-2		
EMC	EN IEC 61000-6-1, EN IEC 61000-6-3		

2.4 Grid codes

No.	National/Regional Grid Code	Description
0	VDE4105-DE	Germany power Grid, meet Grid standards "VDE-AR-N-4105".
1	CEI0-21	Italy power Grid.
2	AS4777	Australia power Grid.
3	RD1699	Spain power Grid.
4	EN50549	Default EN50549 Grid setting.
5	EN50549-DK-W	West Denmark power Grid.
6	Greece	Greece power Grid.
7	EN50549-NL	Netherland power Grid, meet Grid standards "EN50438.
8	C10/11	Belgium power Grid.
9	G99	UK power Grid.
10	China	China power Grid, meet Grid standards "CN-NBT".
11	VDE0126-FR	France power Grid, meet Grid standards "VDE 0126".
12	EN50549-PL	Poland power Grid.
13	Brazil-180s	Brazil power Grid, connect/reconnect time 180s.
14	VDE0126-DE	Germany power Grid, meet Grid standards "VDE 0126".
15	CEI0-16	Italy power Grid, meet Grid standards "CEI 0-16.
16	G98	UK power Grid.
17	Greece Island	Greece Island power Grid.
18	EN50549-CZ	Czech Republic power Grid, meet Grid standards "EN50438Y2007-CZ.
19	IEC61727-IN	India power Grid.
20	Korea	Korea power Grid.
21	EN50549-SW	Sweden power Grid.
22	China-W	China power Grid, Grid voltage range: 160-290V. Grid frequency range: 47-53HZ.
23	China-H	China power Grid.
24	IEC61727-IN-W	India power Grid.
25	Brazil	ABNT NBR 16149/16150.
26	IEC61727-SL	Sri Lanka power Grid, meet Grid standards "IEC61727.
27	Mexico	Mexico power Grid, meet Grid standards "IEC61727 60HZ.
28	NZ4777	New Zealand power Grid, meet Grid standards "NZ4777.
29	Philippines	Philippines power Grid, meet Grid standards "IEC61727 60HZ spec".
30	IEC61727-SL-W	Sri Lanka power Grid, Grid voltage range: 160-280V, Grid frequency range: 47-52HZ.
31	PEA	Thailand power Grid.
32	PEA-W	Thailand power Grid, Grid voltage range: 160-280V, Grid frequency range: 47-52HZ.
33	IEC61727-VN	Vietnam power Grid.
34	IEC61727-VN-W	Vietnam power Grid, Grid voltage range: 160-280V, Grid frequency range: 47-52HZ.

No.	National/Regional Grid Code	Description
35	Tunisia	Tunisia.
36	MEA	Thailand power Grid.
37	MEA-W	Thailand power Grid, Grid voltage range: 160-280V, Grid frequency range: 47-52HZ.
38	Brazil-LV	120V 60Hz voltage of grid L to N(R3-10-15K-LV only, others reserved).
39	EN50549-DK-E	East Denmark power Grid.
40	Tunisia-W	Tunisia wide range.
41	Chile	Chile Power Grid.
42	Brazi-W	Brazil power Grid, meet Grid standards "NBT 16150".
43	EN50549-PL-W	Poland power Grid.
44	Brazil-180s-W	Brazil power Grid, meet Grid standards "NBT 16150".
45	UNE217002-ES	Spain power Grid.
46	G98-N	G98 for Northern Ireland.
47	G99-N	G99 for Northern Ireland.
48	EN50549-NW	Norway-400VLine.
49	EN50549-NW-LV	Norway-230VLine-R3-10-15K-LVonlyothers reserved.
50	IEC61727-LV	133V 50Hz, low voltage power grid.

3. Installation and startup

	<p>WARNING !</p> <p>Before installation and maintenance, AC and DC side doesn't carry electricity, but if DC side is just disconnected, capacitance still contains electricity, so please wait for at least 5 minutes to ensure the capacitors completely release the energy and inverter is not electrified.</p>
	<p>NOTE !</p> <p>Inverters must be installed by qualified person.</p>

3.1 Package information




Figure 3-1 Package information

3.2 Installation environment

- 1) In order to achieve optimal performance, the ambient temperature should be kept lower than 45°C.
- 2) For the convenience of checking the LCD display and possible maintenance activities, please install the inverter at eye level.
- 3) Inverters should not be installed near inflammable or explosive items. Any strong electro-magnetic equipment should be kept away from installation site.
- 4) Product label and warning symbol shall be clear to read after installation.
- 5) Please do not install inverter under direct sunlight, rain and snow.




Figure 3-2 Installation environment

3.3 Installation position



- 1) The installation method and mounting location must be suitable for the inverter's weight and dimensions.
- 2) Mount on a solid surface.
- 3) Select a well-ventilated place sheltered from direct sun radiation.




Figure 3-3 Installation position

In consideration of heat dissipation and convenient dismantlement, the minimum clearances around the inverter should be no less than the following value.




Figure 3-4 Space required of inverters

3.4 Mounting procedure

1. Drill 4 fixed $\Phi 11$ holes in the wall according to the dimensions.




Figure 3-5

2. Fix the wall mounting bracket on the wall with 4 expansion bolts in accessory bag.




Figure 3-6

3. Place the inverter on the wall-mounted bracket and install the fix screw.




Figure 3-7 Mounting the inverter 1




Figure 3-8 Mounting the inverter 2

3.5 Electrical connection

3.5.1 Earth connection

One can additionally earth the inverter enclosure of a second earthed or equipotential bonding, which is required under local regulations. This prevents touch current if the original protective conductor fails.

Cable size: 4mm²

Connection steps:

- Strip the earthed cable insulation.
- Insert the stripped cable into the ring terminal.
- Clamp the end of the ring terminal.
- Unscrew the screw of the earthed connector.
- Insert the ring terminal on the earthed connector.
- Fix the gasket on the earthed connector.
- Tighten the screw of the earthed connector.




Figure 3-9

3.5.2 Connection to the grid (AC output)



- 1) Add breaker or fuse to AC side, the specification should be more than 1.25 times of rated AC output current.
 - 2) The PE line of inverter should be connected to the earth, make sure the impedance of neutral wire and earth wire less than 10 ohm.
 - 3) Disconnect the breaker or fuse between the inverter and the utility.
 - 4) All inverters incorporate a certified internal Residual Current Device (RCD) in order to protect against possible electrocution and fire hazard in case of a malfunction in the PV array, cables or inverter.
- There are 2 trip thresholds for the RCD as required for certification (IEC 62109-2:2011). The default value for electrocution protection is 30mA, and for slow rising current is 300mA.

Connect the inverter to the grid as follows:

1. Strip off L/N/PE cables.




Figure 3-10 Strip off PE/N/L cables

No.	Description	Remark
A	Protective layer	Diameter ranges : 15 - 19mm

No.	Description	Remark
B	Length of stripped off	12mm
C	Insulate layer	50mm
D	Cross section of ac cables	6 - 10mm ²

2. Crimp the terminals with crimping pliers and Set the parts on the cable. Insert the terminal holes in sequence.




Figure 3-11

3. Fully insert the conductors to the corresponding terminal and tighten the screws with the torque $2.0 \pm 0.1 \text{N}\cdot\text{m}$. Pull cables outward to check whether they are firmly installed.




Figure 3-12




Figure 3-13

4. Assemble the housing, the terminal block and cable gland. Make sure that the rib of the terminal block and the groove on the housing engage perfectly until a 'Click' is heard or felt.




Figure 3-14




Figure 3-15

5. Insert the main part of AC connector into the terminal and hear a "click" sound. Complete the installation.




Figure 3-16




Figure 3-17

Unlock AC terminal instructions

1. Use the unlocking tool to press and pull the female end back against the unlocked position to separate it from the inverter end.




Figure 3-18




Figure 3-19

2. Hold the release button in one hand and rotate it in the direction of the marking; turn the nut in the opposite direction with the other hand.




Figure 3-20

3. Use the rubber core removal tool to peel off the red circle position on both sides to complete the removal.




Figure 3-21

3.5.3 Connection to PV string (DC input)



- 1) Before connecting PV string, make sure DC switch is turned off.
- 2) Make sure PV string polarity confirms with DC connector, otherwise, it will cause damage to inverter.
- 3) Make sure the maximum open circuit voltage (Voc) of each PV string does not exceed the inverter input voltage Vmax under any condition.
- 4) Do not connect positive or negative pole of PV string to earth wire. Otherwise, it will cause damage to inverter.




Figure 3-22

3.5.4 Communication

Overview of communication ports:




Figure 3-23 Communication ports

*The RSV_485A and RSV_485B ports are occupied when the AFCI function of the inverter is enabled.

3.5.4.1 WIFI / 4G / Ethernet communication (Optional)

Connect the WIFI / 4G / Ethernet module produced by manufacturer to the COM port of inverter. After successful connection, information such as power generation and running state of the inverter can be viewed via the App on the phone. The details please refer to the WIFI / 4G / Ethernet module user manual.

The block diagram of the WIFI / 4G / Ethernet communication system is as follows:




Figure 3-24

3.5.4.2 CT or Meter Connection (Optional)

The inverter is equipped with the feed-in power limit function, and the communication port on inverter is "CT / Meter" (Figure 3-25, Figure 3-26), below is the method of connecting the CT / Meter in system. Please note that the CT direction must be facing the load and inverter, and the CT must be connected to the fire line.




Figure 3-25




Figure 3-26

3.5.4.3 DRM connection

The inverter supports the demand response modes as specified in the standard AS/NZS4777. The inverter has integrated a terminal for connecting to a DRED. The details please refer to figure 3-23, and for CEI standard, DRM0 is the DI port.

3.5.4.4 Relay connection

The relay can be set to fault alarm output, and user can configure it to be a normal open contact (COM & NO) or a normal close contact (COM & NC). The relay is initially at the NC terminal, and it will trip to another contact when a fault occurs. Use LED indicators or other equipment to indicate whether the inverter is in the faulty state. The following figures show the typical applications of normal open contact and normal close contact:




Figure 3-27 Normal open contact




Figure 3-28 Normal close contact

3.6 Starting the inverter

Before turning on the inverter, please confirm:

- 1) Three AC wires (PE/L/N) cable correctly connected to the inverter AC side through AC circuit breaker;

- 2) The DC cable connected correctly to the inverter DC side through DC circuit breaker, please be attention to the cable connected to the two string correctly and its polarity;
- 3) The unused terminals are covered.

Starting the inverter:

- 1) Turn on the AC circuit breaker between the inverter and the grid;
- 2) Turn on the DC switch on the inverter;
- 3) If the PV panels provide enough energy, the power module will work, and the LCD panel will be lit;
- 4) If you are starting the inverter for the first time, the inverter needs to be commissioned. For example, language, time, etc.
- 5) Then the inverter will turn into self-check mode, and the LCD panel will display the remaining time of connection simultaneously;
- 6) After the inverter turns into normal mode, it feeds electrical energy into the grid, and the LCD panel will display the generated electrical energy.

As long as the inverter works, it will automatically track the maximum power point to absorb the maximum energy from solar. When night comes, the irradiance is not strong enough to provide energy, and the inverter will power off automatically. When the next day comes, the input voltage reaches the start value, and it will start again automatically.

4. User interface

4.1 LED and key






Figure 4-1 LED display

Object	Name	Description
A	Indicator LED	Green: Normal working Status.
B		Red: Fault.
C		Yellow: RS485 communication status.
D	Function Button	ESC button: Leave from current interface or function.
E		Up button: Move cursor to upside or increase value.
F		Down button: Move cursor to downside or decrease value.
G		OK button: Press and hold for 2~3 seconds to confirm the selection.
H	LCD Screen	Display the information of the inverter


4.2 LCD display

Menu Structure:






4.2.1 Language setting




4.2.2 Export power (CT) setting


Setting export control: 1




Setting export control: 2




4.2.3 Data and time setting




4.2.4 PV configuration setting




4.2.5 Communication address setting



4.2.6 Checking error logs




4.2.7 System switch setting




4.2.8 Inverter information checking


The AFCI hardware and software versions are displayed only when the AFCI function is enabled.



4.2.9 Country safety setting




4.2.10 DRMO setting




4.2.11 AFCI setting

To enable the AFCI function, you need to set it up. When electric arcs occur, the inverter will alarm and lock out to provide protection. You need to manually clear the alarm on the inverter so that it can work properly.




4.2.12 Software upgrade


The AFCI can only be upgraded when the AFCI function is enabled.



4.2.13 New password setting



4.2.14 Reset Setting




4.3 Self-Test in accordance with CEI 0-21 (Applies to Italy only)

The self-test is only required for inverters, which are commissioned in Italy. The Italian standard requires that all inverters feeding into the utility grid are equipped with a self-test function in accordance with CEI 0-21. Please note that there is a self-test option only when the inverter selects CEI 0-21. During the self-test, the inverter will consecutively check the protection reaction times and values for overvoltage, under voltage, over frequency and under frequency. Self-test function is available at any time. It also allows end user get test reports shown on LCD display.

There are two ways to execute the self-test:

Auto-Test from screen:



Auto-Test from Solar Admin:

- 1) Download and install "Solar Admin" on laptop
- 2) Connect inverter to laptop via RS485 port.
- 3) When the inverter and "solar admin" are successfully connected. Click "Sys.setting" - "Other" - "AUTOEST" enter into "Auto-Test" interface.
- 4) Click "Execute" to start the test.
- 5) The inverter will automatically run the test until the screen shows "Test end".
- 6) Click "Read" to read the test value, and click "Export" to export the test report.
- 7) After click "Read" button, interface will show the test results, if the test passes, it will show "PASS" if the test is failed it will show "FAIL".

Solar Admin

Inverter 8700831201211006 Number of devices: 1 COM COM1

Overview	History info	Sys.setting	
Protection	Active Power	Reactive Power	other

Reset (factory set)	Italy Autotest <input type="button" value="Execute test"/>		
LVRT settings			
Grid over vol. derating			
Extension Settings			
Basic data settings			
Update (1~3.7K-SS)			
Update (4~8K-DS)			
Update (4~15K-DT)			
Update (10~33K-DT)			
CEI			
AUTOTEST			

<table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="3" style="text-align: center; border-bottom: 1px solid black;">U > (59.S1)</td> </tr> <tr> <td style="width: 33%;"></td> <td style="width: 33%; text-align: center;">Threshold Value</td> <td style="width: 33%; text-align: center;">Reading</td> </tr> <tr> <td>Vmax</td> <td style="text-align: center;">253.0</td> <td style="text-align: center;">224.0</td> </tr> <tr> <td>Trip</td> <td style="text-align: center;">2000</td> <td style="text-align: center;">1987</td> </tr> <tr> <td colspan="3" style="text-align: center;"><input type="button" value="Pass"/></td> </tr> </table>	U > (59.S1)				Threshold Value	Reading	Vmax	253.0	224.0	Trip	2000	1987	<input type="button" value="Pass"/>			<table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="3" style="text-align: center; border-bottom: 1px solid black;">U >> (59.S2)</td> </tr> <tr> <td style="width: 33%;"></td> <td style="width: 33%; text-align: center;">Threshold Value</td> <td style="width: 33%; text-align: center;">Reading</td> </tr> <tr> <td>Vmax</td> <td style="text-align: center;">264.5</td> <td style="text-align: center;">230.5</td> </tr> <tr> <td>Trip</td> <td style="text-align: center;">200</td> <td style="text-align: center;">199</td> </tr> <tr> <td colspan="3" style="text-align: center;"><input type="button" value="Pass"/></td> </tr> </table>	U >> (59.S2)				Threshold Value	Reading	Vmax	264.5	230.5	Trip	200	199	<input type="button" value="Pass"/>			<table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="3" style="text-align: center; border-bottom: 1px solid black;">U < (27.S1)</td> </tr> <tr> <td style="width: 33%;"></td> <td style="width: 33%; text-align: center;">Threshold Value</td> <td style="width: 33%; text-align: center;">Reading</td> </tr> <tr> <td>Vmin</td> <td style="text-align: center;">195.5</td> <td style="text-align: center;">230.2</td> </tr> <tr> <td>Trip</td> <td style="text-align: center;">1500</td> <td style="text-align: center;">1486</td> </tr> <tr> <td colspan="3" style="text-align: center;"><input type="button" value="Pass"/></td> </tr> </table>	U < (27.S1)				Threshold Value	Reading	Vmin	195.5	230.2	Trip	1500	1486	<input type="button" value="Pass"/>		
U > (59.S1)																																															
	Threshold Value	Reading																																													
Vmax	253.0	224.0																																													
Trip	2000	1987																																													
<input type="button" value="Pass"/>																																															
U >> (59.S2)																																															
	Threshold Value	Reading																																													
Vmax	264.5	230.5																																													
Trip	200	199																																													
<input type="button" value="Pass"/>																																															
U < (27.S1)																																															
	Threshold Value	Reading																																													
Vmin	195.5	230.2																																													
Trip	1500	1486																																													
<input type="button" value="Pass"/>																																															
<table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="3" style="text-align: center; border-bottom: 1px solid black;">U << (27.S2)</td> </tr> <tr> <td style="width: 33%;"></td> <td style="width: 33%; text-align: center;">Threshold Value</td> <td style="width: 33%; text-align: center;">Reading</td> </tr> <tr> <td>Vmin</td> <td style="text-align: center;">34.5</td> <td style="text-align: center;">225.0</td> </tr> <tr> <td>Trip</td> <td style="text-align: center;">200</td> <td style="text-align: center;">186</td> </tr> <tr> <td colspan="3" style="text-align: center;"><input type="button" value="Pass"/></td> </tr> </table>	U << (27.S2)				Threshold Value	Reading	Vmin	34.5	225.0	Trip	200	186	<input type="button" value="Pass"/>			<table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="3" style="text-align: center; border-bottom: 1px solid black;">F > (81.S1)</td> </tr> <tr> <td style="width: 33%;"></td> <td style="width: 33%; text-align: center;">Threshold Value</td> <td style="width: 33%; text-align: center;">Reading</td> </tr> <tr> <td>Fmax</td> <td style="text-align: center;">50.2</td> <td style="text-align: center;">50.01</td> </tr> <tr> <td>Trip</td> <td style="text-align: center;">100</td> <td style="text-align: center;">92</td> </tr> <tr> <td colspan="3" style="text-align: center;"><input type="button" value="Pass"/></td> </tr> </table>	F > (81.S1)				Threshold Value	Reading	Fmax	50.2	50.01	Trip	100	92	<input type="button" value="Pass"/>			<table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="3" style="text-align: center; border-bottom: 1px solid black;">F < (81.S1)</td> </tr> <tr> <td style="width: 33%;"></td> <td style="width: 33%; text-align: center;">Threshold Value</td> <td style="width: 33%; text-align: center;">Reading</td> </tr> <tr> <td>Fmin</td> <td style="text-align: center;">49.8</td> <td style="text-align: center;">49.94</td> </tr> <tr> <td>Trip</td> <td style="text-align: center;">100</td> <td style="text-align: center;">92</td> </tr> <tr> <td colspan="3" style="text-align: center;"><input type="button" value="Pass"/></td> </tr> </table>	F < (81.S1)				Threshold Value	Reading	Fmin	49.8	49.94	Trip	100	92	<input type="button" value="Pass"/>		
U << (27.S2)																																															
	Threshold Value	Reading																																													
Vmin	34.5	225.0																																													
Trip	200	186																																													
<input type="button" value="Pass"/>																																															
F > (81.S1)																																															
	Threshold Value	Reading																																													
Fmax	50.2	50.01																																													
Trip	100	92																																													
<input type="button" value="Pass"/>																																															
F < (81.S1)																																															
	Threshold Value	Reading																																													
Fmin	49.8	49.94																																													
Trip	100	92																																													
<input type="button" value="Pass"/>																																															
<table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="3" style="text-align: center; border-bottom: 1px solid black;">F >> (81.S2)</td> </tr> <tr> <td style="width: 33%;"></td> <td style="width: 33%; text-align: center;">Threshold Value</td> <td style="width: 33%; text-align: center;">Reading</td> </tr> <tr> <td>Fmax</td> <td style="text-align: center;">51.5</td> <td style="text-align: center;">51.02</td> </tr> <tr> <td>Trip</td> <td style="text-align: center;">100</td> <td style="text-align: center;">98</td> </tr> <tr> <td colspan="3" style="text-align: center;"><input type="button" value="Pass"/></td> </tr> </table>	F >> (81.S2)				Threshold Value	Reading	Fmax	51.5	51.02	Trip	100	98	<input type="button" value="Pass"/>			<table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="3" style="text-align: center; border-bottom: 1px solid black;">F << (81.S2)</td> </tr> <tr> <td style="width: 33%;"></td> <td style="width: 33%; text-align: center;">Threshold Value</td> <td style="width: 33%; text-align: center;">Reading</td> </tr> <tr> <td>Fmin</td> <td style="text-align: center;">47.50</td> <td style="text-align: center;">50.03</td> </tr> <tr> <td>Trip</td> <td style="text-align: center;">100</td> <td style="text-align: center;">89</td> </tr> <tr> <td colspan="3" style="text-align: center;"><input type="button" value="Pass"/></td> </tr> </table>	F << (81.S2)				Threshold Value	Reading	Fmin	47.50	50.03	Trip	100	89	<input type="button" value="Pass"/>			<input type="button" value="Read"/> <input type="button" value="Export"/>															
F >> (81.S2)																																															
	Threshold Value	Reading																																													
Fmax	51.5	51.02																																													
Trip	100	98																																													
<input type="button" value="Pass"/>																																															
F << (81.S2)																																															
	Threshold Value	Reading																																													
Fmin	47.50	50.03																																													
Trip	100	89																																													
<input type="button" value="Pass"/>																																															

5. Warranty

5.1 Warranty claim procedure

Please report defective device with a brief error description and SN code to our service mail or service hotline for registration. Alternatively, please contact your specific dealer or installer if your unit is defective or faulty. To claim the warranty under the warranty terms of factory, you need to supply us with the following information and documentation regarding the faulty unit:

- 1) Product Model (e.g.R1-8K) and the Serial Number (e.g.8011A33230803006).
- 2) Copy of the invoice and warranty certificate for the inverter.
- 3) Error message on LCD screen and additional information regarding the fault/error.
- 4) Detailed information about the entire system (modules, circuits, etc.).
- 5) Documentation of previous claim/exchanges (if applicable).

In the case of an exchange, the remainder of the warranty entitlement will be transferred to the replacement device. In this event, you will not receive a new certificate, as this replacement will be noted by factory.

5.2 Service after warranty expiration

For products which are out of warranty, factory charges an on-site service fee, parts, labor cost and logistic fee to end-user which can be any/all of:

- 1) On-site attendance fee: Cost of travel and time for the technician in attending on-site;
- 2) Parts: Cost of replacement parts (including any shipping/admin fee that may apply);
- 3) Labor: Labor time fee charged for the technician, who is repairing, maintaining, and installing (hardware or software) and debugging the faulty product;
- 4) Logistic fee: Cost of delivery, tariff and other derived expense when defective products are sent from user to factory or/ and repaired products are sent from factory to user.

6. Troubleshooting and Maintenance


6.1 Troubleshooting

Once a fault occurs in the inverter, the fault information can be displayed on screen or the App interface. Fault codes and check methods are as follows:

No.	LCD display	Possible actions
1	Grid Lost Fault	Grid voltage too low. <ul style="list-style-type: none"> • System will reconnect if the utility is back to normal. • Or seek help from us, if not go back to normal state
2	Grid Volt Fault	Grid voltage out of range. <ul style="list-style-type: none"> • System will reconnect if the utility is back to normal! • Or seek help from us, if not go back to normal state.
3	Grid Freq Fault	Grid frequency out of range. <ul style="list-style-type: none"> • System will reconnect if the utility is back to normal. • Or seek help from us, if not go back to normal state.
4	Vgrid 10M Fault	The grid voltage is out of range for the last 10 Minutes. <ul style="list-style-type: none"> • System will reconnect if the utility is back to normal. • Or seek help from us, if not go back to normal state
5	Inv SW OCP Fault	Disconnect PV, and grid, then reconnect. <ul style="list-style-type: none"> • Or seek help from us, if not go back to normal state.
6	DCI OCP Fault	DC component is out of limit in output current. <ul style="list-style-type: none"> • Disconnect PV, grid and battery, then reconnect. • Or seek help from us, if not go back to normal state.
7	Inv HW OCP Fault	Disconnect PV, and grid, then reconnect. <ul style="list-style-type: none"> • Or seek help from us, if not go back to normal state.
8	Bus Volt Fault	Bus voltage out of range detected by software. <ul style="list-style-type: none"> • Disconnect PV and grid, then reconnect. • Or seed help from us, if not go back to normal state.
9	Iso Check Fault	The isolation is failed. <ul style="list-style-type: none"> • Please check if the insulation of electric wires is damaged. • Wait for a while to check if back to normal.
10	GFCI Fault	The errors are internal faults of the inverter. <ul style="list-style-type: none"> • Disconnect PV, and grid, then reconnect. • Or seek help from us, if not go back to normal state.
11	PV Curt Fault	
12	PV Volt Fault	The errors are configuration faults of the PV panels. <ul style="list-style-type: none"> • Check the configuration of PV panels and cable connections. • Or seek help from us, if not go back to normal state.
13	Temp Fault	The errors are internal faults of the inverter. <ul style="list-style-type: none"> • Disconnect PV and grid, then reconnect. • Or seek help from us, if not go back to normal state.
14	HW Bus Ovp Fault	
15	HW Pv Ocp Fault	
16	SCI Comm Fault	

No.	LCD display	Possible actions
17	SPI Comm Fault	The errors are internal faults of the inverter. • Disconnect PV and grid, then reconnect. • Or seek help from us, if not go back to normal state.
18	Auto test Fault	
19	AD Sample Fault	
20	GFCI HW Fault	
21	Inv EEPROM Fault	
22	Pv NegCurt Fault	
23	Relay Open	
24	Relay S1 Short	
25	Relay S2 Short	
26	Relay M1 Short	
27	Relay M2 Short	The meter connection is lost. • Please check if the meter connection is normal. • Or seek help from us.
28	HMI EEPROM Fault	
29	Meter Lost Fault	

6.2 Maintenance

	<p>Risk of inverter damage or personal injury due to incorrect service!</p> <ul style="list-style-type: none"> • Always keep in mind that the inverter is powered by dual sources: PV strings and utility grid. Before any service work, observe the following procedure. • Disconnect the AC circuit breaker and then set the DC load-break switch of the inverter to OFF. • Wait at least 5 minutes for inner capacitors to discharge completely. • Verify that there is no voltage or current before pulling any connector.
<h1>NOTICE</h1>	<p>NOTICE!</p> <p>Restart the inverter only after removing the fault that impairs safety performance. As the inverter contains no component parts that can be maintained, never arbitrarily replace any internal components. For any maintenance need, please contact Renac Power. Otherwise, Renac Power shall not be held liable for any damage caused.</p>

6.2.1 Routine Maintenance

Item	LCD display	Period
System clean	Check the temperature and dust of the inverter. Clean the inverter enclosure if necessary. Check if the air inlet and outlet are normal, Clean the air inlet and outlet if necessary	Six months to a year (- depend on the dust contents in air.)
Cable entry	Check whether the cable entry is insufficiently sealed or the gap is excessively large, and reseal the entry when necessary!	Once a year
Electrical Connection	Check whether all cable are firmly in place. Check whether a cable is damaged, especially the part contacting the metal enclosure.	Six months to a year

Maintenance Instruction

Cleaning Air Inlet and Outlet

A huge amount of heat is generated in the process of running the inverter. The inverter adopts a controlled forced-air cooling method. In order to maintain good ventilation, please check to make sure the air inlet and outlet are not blocked. Clean the air inlet and outlet with soft brush or vacuum cleaner if necessary.



User Manual Download Centre www.renacpower.com

422-00222-00

SMART ENERGY FOR BETTER LIFE

RENAC

RENAC POWER TECHNOLOGY CO., LTD.

Block C-12, No. 20 Datong Road, Comprehensive Bonded Zone, Suzhou Hi-Tech District, Suzhou, China

Tel: +86-0512-66677278

info@renacpower.com

www.renacpower.com